



WHERE TO START ?



Choose the
FLATSCAN 3D SW
for your
SWING DOOR

Choose your kit

The **LZR®-FLATSCAN 3D SW** is available in different packages, and different colours.

Do you want to secure a one-leaf door ?

A double swing ?

Do you want full coverage ?

Go through our different packages to find the one that fits your application and discover our range accessories.



LZR®-FLATSCAN 3D SW KIT



02.0861
00000-00xx



02.0861
00000-01xx



02.0861
00000-02xx



Choose your (single) kit





LZR®-FLATSCAN 3D SW RIGHT

02.0863 00000-00xx	02.0863 00000-01xx	02.0863 00000-02xx

LZR®-FLATSCAN 3D SW LEFT

02.0862 00000-00xx	02.0862 00000-01xx	02.0862 00000-02xx

Choose your (mixed) kit



LZR®-FLATSCAN SW PACK 3D LEFT

LZR®-FLATSCAN SW PACK 3D RIGHT



02.0864
00000-00xx

02.0864
00000-01xx

02.0864
00000-02xx



02.0865
00000-00xx

02.0865
00000-01xx

02.0865
00000-02xx

Any accessories ?

Some accessories enhanced the experience of the **LZR®-FLATSCAN 3D SW**.

Need a discreet solution for glass doors?
You might want to choose the glass door accessory.
Make no compromise: choose safety AND design.

The **LZR®-FLATSCAN 3D SW** has an additional output dedicated to the opening of the door.
Multiple virtual opening buttons can be placed everywhere in the detection field to intentionally open the door.
We've created a series of stickers to make them visible.



GLASS DOOR ACCESSORY



02.0768
00000-0042

02.0768
00000-0043

02.0768
00000-0044

VIRTUAL OPENING BUTTON LABEL



02.0768
00000-0063

02.0768
00000-0065

02.0768
00000-0064

02.0768
00000-0066