


5 Swing Door Operator, SW100



Pos.	Art. No.	Description
1	331003498	Transmission unit
2	331003532	Control unit CU-ESD
2a	331003554	EXU-SI (Kit to extend the security functions)
2b	331003557	EXU-SA (Kit to extend the safety functions)
3	331700607	Mains contact
4A	330000230	Door stop. Transmission unit until w.1952.
4B	331019378	Stop arm kit. Transmission unit from w.1952.
5	331011797	Mounting kit
5a	331003578	Cable holder* (50 pcs)
6	331003543BK	Bottom end plate SW100/SW200
	331003543SI	Bottom end plate SW100/SW200
7	331009683	Cover Length CL=716mm, state high energy performance level and surface treatment
	331009934	State cover length CL, R and/or S, high energy performance level and surface treatment
8	331003582	On/Off/Hold open switch
9	331003567	Battery backup unit SW100 (EU)
	1004437	Connection box (US)
10	331003583	Sync cable
11	331008749BK	Top end plate SW100/SW200
	331008749SI	Top end plate SW100/SW200
12	330000233	Encoder cable
14	330000270BK	Adaptor kit
	330000270SI	Adaptor kit
15	330000271BK	Push arm service kit
	330000271SI	Push arm service kit
16	330000335BK	Pull arm service kit (EU)
	330000335SI	Pull arm service kit (EU)
	330000272BK	Pull arm service kit (US)
	330000272SI	Pull arm service kit (US)
17	1006340	Cable kit (EU)
18	331009513BK	Fill cover kit
	331009513SI	Fill cover kit
19	331015578BK	Middle cap (2 pcs)
	331015578SI	Middle cap (2 pcs)
20	331006504	Fixing kit transmission unit
20a	331003507	Allenkey head nut
21	331019159	Microswitch kit
22	331012753	Backplate
23	331003508	Clock spring