


7 Swing Door Operator, SW300/SW150



Pos.	Art. No.	Description
1	33738753	Battery NiMH 12V/1.2Ah
2	331003554	EXU-SI Kit for Security & Impulse
3	331003557	EXU-SA Kit for Safety
4	331003583	Cable sync kit
5	330000331	Battery extension Cable
6	331009105	Encoder Cable
7	331007819F	Transmission Unit kit SW300
	331009148	Transmission Unit kit SW150
8	331007845	Micro Switch Kit
9	331007849	Stop Arm Kit
10	331008333	Control Unit CU-300
11	331008344	Single Door Connection Box
12	331009166	Off/Auto/Open Switch
13A	331009183	Fixing kit. Transmission unit until w.1845.
13B	331017941	Fixing kit FB. Transmission unit from w.1845.
14	331009513BK	Fill cover
	331009513SI	Fill cover
15	331009515	Single cover, state BK/SI and Surface treatment
	331009584	Double Full Length Cover, state BK/SI, CL, R and S and Surface treatment
16	331013027	Coordinator top assembly kit
17	331013050	Rod kit
18	330000682	Coordinator service kit
19	330000684	Fixing for control unit CU-300
20	331007823	Battery assembly SW300
21	331007825BK	Bottom end plate SW300
	331007825SI	Bottom end plate SW300
22	331007829BK	Top end plate SW300
	331007829SI	Top end plate SW300
23	331008615	LED cable SW200/SW300
24	331009828	Reset & Indication device SW200/SW300
25	331010374	Closing brake kit SW300
26	331009903	Micro switch board & cam. For double action doors only
27	330000270BK	Adaptor kit
	330000270SI	Adaptor kit
28	330000271BK	Push arm service kit
	330000271SI	Push arm service kit
29	330000335BK	Pull arm service kit
	330000335SI	Pull arm service kit
30	331007821	Back plate
	331014103	Full back plate. State CL, R and /or S.
31	331015579BK	Middle cap SW300 (2 pcs)
	331015579SI	Middle cap SW300 (2 pcs)
32	331012324	Cover kit CU-300